



Installation of Perimeter Seals: Gasket System E

1. Install the Pemko 434 door bottom in accordance with the manufacturer's instructions prior to hanging the door.
2. Turn the adjustment screw on the door bottom in so that the seal will not activate when the door is closed.
3. Hang the door and adjust for proper clearances.
4. Turn the adjustment screw on the door bottom out to the point where the seal makes uniform firm contact with the sill when the door is closed. If a flat threshold is being used as the sill a sealant, such as silicone caulk, should be used to prevent sound transmission between the threshold and floor. Door bottoms should not be used over carpeted sills as this will not provide a good seal.
5. Measure and cut the Pemko 303 seals to cover the full width and height of the opening. If a flat threshold is being used that extends inside the frame stops the Pemko 303 seals should be cut to butt tight to the threshold.
6. Position the Pemko 303 seals on the frame stop so the seals are slightly compressed against the face of the door in the closed position. Attach the seals to the frame using the screws provided with the seals. To prevent transmission leaks in the corners, silicone caulking should be used where the header and jamb seals meet.



Eggers Industries

Stile & Rail Doors, Door Frames,
Plywood, Veneered Components

Two Rivers Division
One Eggers Drive
Two Rivers, WI 54241
Phone: 920.793.1351
Fax: 920.793.2958

www.eggiersindustries.com

Flush Doors

Neenah Division
164 North Lake Street
Neenah, WI 54956
Phone: 920.722.6444
Fax: 920.722.0357

email: sales@eggiersindustries.com